FLUID TEMPERATURE 160.0 Fahrenheit

CUTTING (TREATMENT) INTERVALS

	INTERVAL (#)	START (feet)	END (feet)	TIME (start)	TIME (finish)
Bottom	1	4914.83	4916.14	0:00	0:00
	2	4912.86	4914.17	0:00	0:00
	3	4910.89	4912.20	0:00	0:00
	4	4908.59	4910.23	0:00	0:00
	5	4906.30	4907.94	0:00	0:00
	6	4904.00	4905.64	0:00	0:00
	7	4886.48	4888.12	0:00	0:00
	8	4884.19	4885.83	0:00	0:00
	9	4881.89	4883.53	0:00	0:00
	10	4879.59	4881.23	0:00	0:00
	11	4877.30	4878.94	0:00	0:00
Topping	12	4875.00	4876.64	0:00	0:00

CONVERTER



additional info: volume of water in the well equal 2704 (calculation of the level of water by volume in the well) (bbl) (gal) (feet) water volume without tubing: 5225 (ft) 124.37 5223 water volume with tubing on the first cutting interval 111.12 4667 4915 water volume with tubing on the last cutting interval 111.23 4672 (ft) 4875 (bbl) (gal) hydrostatic pressure ft equal 4914.83 2201.51 psi sand→nozzl 3.73 2 nozzles abrasive quartz sand 10/35 20/40 4 nozzles 22.3 43.2 PUMP (FRAC) (Required surface equipment and materials): high-pressure (triplex or more) frac-pump for operate in the following mode (max/min): Concentrat **GROSS time** nozzles Pressure Rate Slurry Density NET time 5500 6.0 252 2.67 8.42 8 2 12 6500 9.0 378 2.67 8.42 12 16 (pieces) (bbl/min) (gal/min) (ounces/gal) (ppt) sand hopper or dump truck compatible with blender concentration: 2.67 (ounces/gal) 16 high pressure iron tubing, including connections the length of (feet) 100 17 reverse flow manifold (opportunity to catch the valve ball on the surface at back flushing) Frac Van (opportunity for monitoring working pressure, sand concentration, slurry rate) prepare and connect high pressure line. test the operation of pump aggregates and sand flow in the blender. test the high pressure line before wellhead 10 disconnect high pressure line from wellhead, drop the testing ball (2"), connect again. 11 wait ~ (push the test ball with a little pressure) ~ 300 min test tubing connections with the pressure ~ 12 6779 during switch manifold block, turn back flushing, catch the ball through the free pipe connection. 13 14 switch manifold block, disconnect high pressure line at wellhead, drop the metal valve ball (1"). 15 wait ~ 300 min (push the test ball with a little pressure) ~

Avoid a sharp increase in pressure, avoid hydraulic impact the ball on tool and perforator. During the

slotting perforation process avoid a sharp increase in pressure, pressure jumps when applying sand, the pressure must be constant. Avoid increasing the pressure above 5900 psi. When the shock pres-

sure above this, tool stops working. With a decrease in pressure is less than 800 psi perforator returns to the starting position. Avoid of jumping the sand concentration, avoid supplying the sand by packs,

this leads to clogging of the tool and hydraulic impact. Do not allow to stop the circulation of the working solution, in an emergency stop circuit immediately start back flushing to prevent sand filling tool.

